

**RECAMBIOS
COD. 62022**





HM-22D-Z-01
Palas principales

Cod. 62201



HM-22D-Z-02
Estabilizadores

62202



HM-22D-Z-03
Var.palas estabilizad.

62203



HM-22D-Z-04
Cabeza rotor

62204



HM-22D-Z-05
Juntas cabeza rotor

Cod. 62205



HM-22D-Z-06
Jgo. Conectores servo

62206



HM-22D-Z-07
Barra servo cola

62207



HM-22D-Z-08
Fijacion cabina

62208



HM-22D-Z-09
Cuadro rotor

Cod. 62209



HM-22D-Z-10
Soporte rotor

62210



HM-22D-Z-11
Jgo. Alerones

62211



HM-22D-Z-12
Volante rotor

62212



HM-22D-Z-13
Varilla soporte cola

Cod. 62213



HM-22D-Z-14
Soporte servo cola

62214



HM-22D-Z-15
Trineo

62215



HM-22D-Z-16
Soporte Motor

62216



HM-22D-Z-17
Sop./tor. varrilla cola

Cod. 62217



HM-22D-Z-18
Cuerpo principal

62218



HM-22D-Z-19
Eje principal

62219



HM-22D-Z-20
Engranaje principal

62220



HM-22D-Z-21
Palas traseras

Cod. 62221



HM-22D-Z-22
Juego parte rotor

62222



HM-22D-Z-23
Engranajes traseros

62223



HM-22D-Z-24
Soporte rotor cola

62224



HM-22D-Z-25
Transmision

Cod. 62225



HM-22D-Z-26
Tubo de cola

62226



HM-22D-Z-27
Cabina

62227



HM-22D-Z-28
Prisioneros de aluminio

62228



HM-22D-Z-29
Rodamientos

Cod. 62229



HM-22D-Z-30
Jgo. Tornilleria

62230



HM-22D-Z-31
Motor

62231



HM-22D-Z-32
Servos

62232



HM-22D-Z-33
Receptor

Cod. 62233



HM-22D-Z-34
Bateria

62234



HM-22D-Z-35
Juego accesorios

62235



HM-22D-Z-36
Cargador

62236



HM-22D-Z-37
Emisora

Cod. 62237



HM-22D-Z-38
Cristales frecuencia

62238